Anywhere Video

The Complete User Manual







Services provided by Fahrenheit 451

Table of Contents

Accessing Anywhere Video from Your Browser 2
- Logging In from Your Internet Browser 2
- The Anywhere Video Viewing Toolbar 4
- Navigating Your Past Video Footage 6
- Recorded Video Playback 8
- Note for Exporting Video Footage 8

Using Anywhere Video on the Onsite Computer 9
- Viewing Cameras 9
- Saving Your View 9
- Creating Camera Groups 10
- Searching and Reviewing Video 12
- Tools for Exporting Images or Video 14
- Saving an Image from Recorded Video 14
- Saving a Video Clip from Recorded Video 14
- Copying the Exported Video to a CD-ROM 15

Accessing Anywhere Video from Your iOS / Android Device 17
- Adding Your Site to Your Device 17
- Viewing Camera Footage on Your Device 19
- Searching Your Past Video Footage on Your Device 23

Accessing Anywhere Video from Another Smart Phone 25

Accessing Anywhere Video from Your Browser

Internet Explorer, Firefox, Safari, Chrome or Opera.

Logging In from Your Internet Browser

To access your video system from your Internet Browser (Internet Explorer, Safari, Firefox, Chrome or Opera), type the following URL listed in your log-in information (see your personalized log-in sheet).

You will be greeted with the screen below.


Advanced
The advanced interface is like the client software and allows for multiple server connections, drag and drop to the virtual matrix, and searching recorded video.
Tested Browsers: Internet Explorer 7 & 8, Firefox 2.0 & up, Safari 3 & up, Google Chrome 1 & up, Mobile Safari (iPhone)
Simple
Username:
Password:
exacqVision Server
Go

Provided you are using a broadband connection (Cable or DSL), you should always choose “Advanced” by clicking on the word itself. You will then be taken to the screen below.



In the left hand column click on the words “+Add Server”. Once you have added a server you will be given the option to login.



Use the Username and Password given for your Internet Browser Login (see your separate personalized log-in sheet).



If successful you will be greeted with a list of cameras in the left column.



The Anywhere Video Viewing Toolbar

The toolbar for Anywhere Video is extremely similar no matter where you access it from; your on-site computer or through the internet.

Take the time to familiarize yourself with the icons and their functions.

	Return to Live Video	Returns to live video from the search panel.
	Search Video Feed	Takes you the search time frame panel.
	1 Camera View	Allows you to view one camera at a time.
	4 Camera View	Allows you to view 4 cameras at a time.
	7 Camera View	Allows you to view 7 cameras at a time.
	10 Camera View	Allows you to view 10 cameras at a time.
	13 Camera View	Allows you to view 13 cameras at a time.
	16 Camera View	Allows you to view 16 cameras at a time.
	8 Camera View	Allows you to view 8 cameras at a time.
	6 Camera View	Allows you to view 6 cameras at a time.
	9 Camera View	Allows you to view 9 cameras at a time.
	Show Pan / Tilt Controls	If your camera supports pan / tilt, this will bring up the arrows to control the camera's view.
	Hide Sidebar	This will hide the sidebar on the left containing your list of cameras.

Viewing Your Cameras (Internet Browser)

Once you have chosen your camera configuration by clicking on the desired camera view (1 – 16 Cameras), you can drag individual cameras to the empty grey squares to populate them.



To view your cameras in order, simply double click on the first camera and it will populate all of your cameras in order.



Using Pan / Tilt (on Supported Cameras)

You can double click on any camera to view it in the full window. You can also use the pan / tilt controls (if the camera supports this function. If you are unsure, please contact our office for more information) by selecting the "Show Pan / Tilt Controls" button from the top toolbar.

This will bring up additional green buttons (pictured above on the right) with arrows that will allow you to direct the view of the camera. Ensure that when you are finished viewing the camera that you return it to the desired location of surveillance.

Navigating Your Past Video Footage

Click on the "Search" button to bring up a new window on the left that will allow you to browse past video footage.



Click on the camera(s) you wish to view and ensure that a check mark in the box next to the prefered name.



Above the list of cameras there will be the words “Start” with a date and time next to it. If you click on the date, a calendar will appear to help you choose the start date of video footage you would like to view. Select the date, and then choose the desired start time (found to the left below the date). When completed, click “Set”. Repeat these steps for the “End” date and time. Once you have selected your desired beginning and ending time, click “Start Streaming” below.

This will bring up a stream of video footage from the camera and time frame you have selected. To view and control the video footage more easily, you can use the video playback options found at the bottom.

Recorded Video Playback

The buttons on the bottom of the window will allow you to control the play back speeds as well to pause the video.

	Rewind (High Speed)	Rewinds at high speeds of x2, x4, x32, and more.
	Rewind (Slow Speed)	Rewinds at half speeds of x0.5, x0.25, and less.
	Pause	Allows you pause the video at any point.
	Forward (Slow Speed)	Moves forward at half speeds of x0.5, x.25 and less.
	Forward (High Speed)	Moves forward at high speeds of x2, x4, x32, and more.

Note for Exporting Video Footage

You can review footage from the anywhere on the Internet, but in order to export the video footage, you must use the on-site computer. If Fahrenheit 451 is hosting your video service, please contact us to request a specific portion of video and we will gladly export it for you. If you have any questions or concerns, please contact our office for further assistance.

Using Anywhere Video on the Onsite Computer

Mac OS X or Windows 7

To access your video system from your onsite computer (the computer where the video is being recorded), log-on to the Windows sytem and launch “ExacqVision” from the Start Menu (or from Applications on Mac OS X).

Viewing Cameras

The program will offer much of the same functionality as the Internet Browser Version. From the live camera view you will be able to choose the number of viewing screens and drag the cameras to the windows (see instructions on using camera views in the “Accessing Anywhere Video from Your Browser” section).

Saving Your View

Once you have arranged your cameras in the desired viewing format (with the correct cameras displayed in each window) you can save the view to easily access it later. While in the “Live Camera” tab, you can click “Save View”

The Save Views window will appear and give you the option to name your current view. When you are finished typing in the desired name click “Apply”.



The view you have created will now be visible under the “Views” Tab.

Creating Camera Groups

There is an additional tab called “Groups”, available on the on-site computer. It can be found on the left hand side of the screen. You can create custom arrangements of cameras, such as by floor or by type. To create a custom camera group click on the “Settings” button.

Once in the Settings Panel, select “Group Setup” from the left hand pane. From here you will be given the option to create groups and assign cameras to those groups.



Begin by clicking “New”, then enter a Group Name, Description and Choose an Icon. Next, you can add cameras to the group by selecting the camera names and clicking “Add > >” . Once you have added all the necessary cameras to your group, click “Apply” to save the changes.



When you return to the viewing page, (Icon of the Computer Screen). You will see the “Groups” tab where you can now view your cameras in their assigned groups.

Click on on a group to view the cameras within that group. They can also be dragged to your viewing screens.



Searching and Reviewing Video

To view recorded video footage from the past, click on the “Search” Button in the toolbar. This will take you to the Search page.

To begin searching you will need to select which cameras you wish to review. You can do this by checking the boxes in the left hand window pane (Note, you can select multiple cameras).



Next, you must to select a relevant start date and time from the calendar on the right hand side. Once a date and time have been selected, click “Search”. Generally the search will show you the next hour and half after the start time.



Once you have begun your search, you will be shown a timeline that indicates when motion has occurred. To scrub along the timeline, simply click in the timeline area where you would like to view your video feed.

Motion No Motion



You can also search entire Views or Groups, by opening the View or Group and then switching to the Search Page (click the "Search" Icon). You will see all of the timelines for the cameras side-by-side as well as the camera footage shown in the viewing screens on above.



Tools for Exporting Images or Video

To export an image or video from Anywhere Video, you must begin by generating a search. Once you have a timeline of video, you can use the following tools

Saving an Image from Recorded Video

Click on the video timeline to place the marker. Click the play button on the video and then pause it once you have the desired frame on your screen (see the slow motion playback detailed in "Playing Back Recorded Video"). Once you can see your desired frame, click the Image Icon (pictured above). Next, you will be prompted to save the image file.

Saving a Video Clip from Recorded Video

	Save Image	Allows you to save the current frame of video as an image file on the computer.
	Save Video Clip	Allows you to export a video file between two marked points of the recording.
	Print Image	Allows you to print the current frame of a video directly to a printer that is connected on the current computer.
	Copy Videos to Disc	Allows you to copy already exported Video Clips to a CD-ROM.

Once you have the correct timeline loaded for the the video you will be extracting, place your marker (indicated by the black and yellow line) on the beginning of clip by clicking on the timeline. Once the marker is placed, right click and select "Mark Export Start". Next, move the marker to where you would like the video to end and then click "Mark Export Stop".



Once you have marked an Export Start and Export Stop, the "Export Video" option will be selectable when you right click on the timeline. This will bring up a window allowing you to save the file to your computer. Select the "Save As Type" and choose "AVI Files (*.avi)" or "QuickTime (*.mov)" as these are relatively standard.



Copying the Exported Video to a CD-ROM

Once you have created your video files, you can transfer them to a USB Drive, External Hardrive or Shared Folder on a Network. If you need to provide the video files to the police, you may opt to copy the files onto a CD. This/Anywhere Video software can help you to easily do this.

Click the the CD burning icon from the Search Page. A window will pop up with a list of all your exported video and allow you to check off the ones you wish to copy to the disc. Once you have selected your files, click “Burn Disc” to begin your burning process.



Accessing Anywhere Video from Your iOS / Android Device

On your iPhone, iPad, or Android phone you can download a free app to access your Anywhere Video system. This app is called “exacq Mobile 2” created by “Exacq Technologies, Inc” and can be downloaded from the Apple App Store or the Android Market. Once downloaded and installed, run “exacq Mobile 2”.

Adding Your Site to Your Device



Upon opening the app, you should be on the “Settings” page. If you are not, click “Settings” from the bottom tabs.

Once you are in the settings tab, you will be able to view any Web Server that has been installed or, you can Add a Web Server by clicking “exacqVision Web Server”.

This will take you to a screen requiring you to input details of your system.



To add a new system you will need to provide the correct site credentials.

First, enter a "Friendly Name" that will appear in your phone as the name of your site. It can be anything you like.

Next, enter the information outlined in "Your Log-In Credentials" found on your separate personalized log-in sheet.



Once your system has been added you will be able to click on it from the Settings page.

The first time you attempt to access your site however, you will be required to enter your password.

See "Your Log-In Credentials" found on your separate personalized log-in sheet.



Once you are connected to your site you will see a list of available cameras.

From the settings tab, you will not be able to view these cameras, you will only be able to see that you are correctly connected to the site.

Move over to the “Live” tab to view the live camera footage

Viewing Camera Footage on Your Device



On the “Live” tab you will be able to select your cameras and your desired layout.

To begin, click “Layout”.



A list of layouts ranging from 1 to 16 screens will be presented allowing you to choose those that fulfills your needs.

Once selected you will return to the previous screen.



To add live surveillance footage to your views you will need to click “Cameras”. It will then bring up a list of servers and available cameras.



When going to select a camera, you will first need to choose the site, then the list of cameras will appear.



From the list of cameras, choose the one you wish to add to your viewing page.



Once you have added your first camera, you can click “Cameras” again to add your second, third, and so on.

The app should save your desired view for the next time you launch it. You can double tap on any one video screen for a larger view.

To return to a multiple screen view, simply hit “Layout” again.



To clear a specific camera from your layout, you can hold your finder over that camera and a pop up menu will appear. Click “Clear” and that camera will be removed from your view. It can still be re-added later.

By holding your finger over the camera image you can also capture or e-mail a still shot of the current frame of the video footage.

Searching Your Past Video Footage on Your Device



Clicking on the "Search" tab will allow you to view past footage for one of your cameras. The viewing is limited to a ten minute window. If you are looking to examine a larger timeframe it is recommended that you use the on-site computer.

To begin searching, click on the desired camera.

*Note: only cameras that are added to your view under the "Live" tab will be searchable.



To begin your search, determine how many minutes you would like the video clip to be then select the date and time of when it will start.

Upon clicking "Done" you will receive the video footage for the specified camera during the set date and time period.



Upon submitting your search query you will be shown a clip of your requested video.

The video can be controlled with the buttons on the top (back, play/pause, forward).

You can srub the video by moving your finger along the timeline.

To refine your search click “Time”, you will then be returned to the search options. To search a separate camera, click the “Search” tab on the bottom again and it will refresh.

*Please Note: Searching video on your mobile device can be taxing on the processor and may not produce the best results. When reviewing your footage it may be best to use your Internet browser or on-site computer.

Accessing Anywhere Video from Another Smart Phone

For other mobile smart phones that do not have native apps designed for their operating systems, you can simply follow the same directions for “Accessing Anywhere Video from your Internet Browser”. Most of the functionality should be available.